



S1	S2	Mode
OFF	OFF	Auto swing(back/for)
ON	OFF	Single swing(back/for)
OFF	ON	Single triggering
ON	ON	Momentary control



Motor driver



	ECNC-S04 stepper controller
	Lightobject.com